OSVP Clip Documentation

Introduction

The OSVP Clip (clip) is a collection of metadata parameters sampled over a specified duration. Each parameter is either:

- static: the parameter has at constant value over the duration of the clip
- dynamic: the parameter is sampled at regular intervals over the duration of the clip

Each parameter is identified by a unique name. It also has a general description as well as a specific set of constraints.

The OSVP Frame (frame) is a collection of metadata parameters that is dynamic and has a synchronous relationship with a video frame. In an OSVP environment this describes live camera position ('tracking') and lens data.

Clip Parameters

Description

duration

Duration of the clip

Units

second

Sampling

Static

Constraints

The parameter shall be a rational number whose numerator is in the range [0..2,147,483,647] and denominator in the range (0..4,294,967,295].

captureFrameRate

Description

Capture frame rate of the camera

Units

hertz

Sampling
Static
Constraints
The parameter shall be a rational number whose numerator is in the range [02,147,483,647] and denominator in the range (04,294,967,295].
activeSensorPhysicalDimensions
Description
Height and width of the active area of the camera sensor in microns
Jnits
millimeter
Sampling
Static
Constraints
The height and width shall be each be real non-negative numbers.
activeSensorResolution
Description
Photosite resolution of the active area of the camera sensor in pixels
Jnits
pixel
Sampling
Static
Constraints
Γhe height and width shall be each be an integer in the range [02,147,483,647].
make
Description
Non-blank string naming camera manufacturer

Units

Compline
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
model
Description
Non-blank string identifying camera model
Units
None
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
serialNumber
Description
Non-blank string uniquely identifying the camera
Units
None
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
firmwareVersion

Description

None

Non-blank string identifying camera firmware version

Units
None
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
label
Description
Non-blank string containing user-determined camera identifier
Units
None
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
anamorphicSqueeze
Description
Nominal ratio of height to width of the image of an axis-aligned square captured by the camera sensor. It can be used to de-squeeze images but is not however an exact number over the entire captured area due to a lens' intrinsic analog nature.
Units
None
Sampling
Static
Constraints
The parameter shall be a rational number whose numerator is in the range [02,147,483,647] and denominator in the range (04,294,967,295].

isoSpeed

Description
Arithmetic ISO scale as defined in ISO 12232
Units
None
Sampling
Static
Constraints
The parameter shall be a integer in the range (14,294,967,295].
fdlLink
Description
URN identifying the ASC Framing Decision List used by the camera.
Units
None
Sampling
Static
Constraints
The parameter shall be a UUID URN as specified in IETF RFC 4122. Only lowercase characters shall be used. Example: f81d4fae-7dec-11d0-a765-00a0c91e6bf6
shutterAngle
Description
Shutter speed as a fraction of the capture frame rate. The shutter speed (in units of 1/s) is equal to the value of the parameter divided by 360 times the capture frame rate.
Units
degree
Sampling
Static
Constraints

The parameter shall be a real number in the range (0..360].

distortionOverscanMax

Description

Sampling

g

each frame. Note it should be the maximum of both projection-matrix-based and field-of-view-based rendering as per the OpenLensIO documentation.
Units
None
Sampling
Static
Constraints
The parameter shall be a real number >= 1.
undistortionOverscanMax
Description
Static maximum overscan factor on lens undistortion. This is alternative to providing dynamic overscan values each frame. Note it should be the maximum of both projection-matrix-based and field-of-view-based rendering as per the OpenLensIO documentation.
Units
None
Sampling
Static
Constraints
The parameter shall be a real number >= 1.
make
Description
Non-blank string naming lens manufacturer
Units
None

Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
mode1
Description
Non-blank string identifying lens model
Units
None
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
serialNumber
Description
Description Non-blank string uniquely identifying the lens
Non-blank string uniquely identifying the lens
Non-blank string uniquely identifying the lens Units
Non-blank string uniquely identifying the lens Units None
Non-blank string uniquely identifying the lens Units None Sampling
Non-blank string uniquely identifying the lens Units None Sampling Static
Non-blank string uniquely identifying the lens Units None Sampling Static Constraints
Non-blank string uniquely identifying the lens Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints.
Non-blank string uniquely identifying the lens Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints. firmwareVersion
Non-blank string uniquely identifying the lens Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints. firmwareVersion Description
Non-blank string uniquely identifying the lens Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints. firmwareVersion Description Non-blank string identifying lens firmware version

Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
nominalFocalLength
Description
Nominal focal length of the lens. The number printed on the side of a prime lens, e.g. 50 mm, and undefined in the case of a zoom lens.
Units
millimeter
Sampling
Static
Constraints
The parameter shall be a real number greater than 0.
calibrationHistory
Description
List of free strings that describe the history of calibrations of the lens.
Units
None
Sampling
Static
make
Description
Non-blank string naming tracking device manufacturer
Units
None
Sampling

Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
model
Description
Non-blank string identifying tracking device model
Units
None
Sampling
Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
serialNumber
Description
Description Non-blank string uniquely identifying the tracking device
Non-blank string uniquely identifying the tracking device
Non-blank string uniquely identifying the tracking device Units
Non-blank string uniquely identifying the tracking device Units None
Non-blank string uniquely identifying the tracking device Units None Sampling
Non-blank string uniquely identifying the tracking device Units None Sampling Static
Non-blank string uniquely identifying the tracking device Units None Sampling Static Constraints
Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints.
Non-blank string uniquely identifying the tracking device Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints. firmwareVersion
Non-blank string uniquely identifying the tracking device Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints. firmwareVersion Description
Non-blank string uniquely identifying the tracking device Units None Sampling Static Constraints The parameter shall be a Unicode string between 0 and 1023 codepoints. firmwareVersion Description Non-blank string identifying tracking device firmware version

Static
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
notes
Description
Non-blank string containing notes about tracking system
Units
None
Sampling
Regular
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
recording
Description
Boolean indicating whether tracking system is recording data
Units
None
Sampling
Regular
Constraints
The parameter shall be a boolean.
slate
Description
Non-blank string describing the recording slate
Units

Sampling

None

Sampling
Regular
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
status
Description
Non-blank string describing status of tracking system
Units
None
Sampling
Regular
Constraints
The parameter shall be a Unicode string between 0 and 1023 codepoints.
mode
Description
Enumerated value indicating whether the sample transport mechanism provides inherent ('external') timing, or whether the transport mechanism lacks inherent timing and so the sample must contain a PTP timestamp itself ('internal') to carry timing information.
Units
None
Sampling
Regular
Constraints
The parameter shall be one of the allowed values.
recordedTimestamp
Description

PTP timestamp of the data recording instant, provided for convenience during playback of e.g. pre-recorded tracking data. The timestamp comprises a 48-bit unsigned integer (seconds), a 32-bit unsigned integer

(nanoseconds)
Units
second
Sampling
Regular
Constraints
The parameter shall contain valid number of seconds, nanoseconds elapsed since the start of the epoch.
sampleRate
Description
Sample frame rate as a rational number. Drop frame rates such as 29.97 should be represented as e.g. 30000/1001. In a variable rate system this should be estimated from the last sample delta time.
Units
None
Sampling
Regular
Constraints
The parameter shall be a rational number whose numerator is in the range [02,147,483,647] and denominator in the range (04,294,967,295].
sampleTimestamp
Description
PTP timestamp of the data capture instant. Note this may differ from the packet's transmission PTP timestamp. The timestamp comprises a 48-bit unsigned integer (seconds), a 32-bit unsigned integer (nanoseconds)
Units
second
Sampling
Regular
Constraints
The parameter shall contain valid number of seconds, nanoseconds elapsed since the start of the epoch.

sequenceNumber

Description

Integer incrementing with each sample.

Units

None

Sampling

Regular

Constraints

The parameter shall be a integer in the range (0..4,294,967,295].

synchronization

Description

Object describing how the tracking device is synchronized for this sample.

frequency: The frequency of a synchronization signal. This may differ from the sample frame rate for example in a genlocked tracking device. This is not required if the synchronization source is PTP or NTP. locked: Is the tracking device locked to the synchronization source offsets: Offsets in seconds between sync and sample. Critical for e.g. frame remapping, or when using different data sources for position/rotation and lens encoding present: Is the synchronization source present (a synchronization source can be present but not locked if frame rates differ for example) ptp: If the synchronization source is a PTP leader, then this object contains:

- "profile": Specifies the PTP profile in use. This defines the operational rules and parameters for synchronization. For example "SMPTE ST2059-2:2021" for SMPTE 2110 based systems, or "IEEE Std 1588-2019" or "IEEE Std 802.1AS-2020" for industrial applications
- "domain": Identifies the PTP domain the device belongs to. Devices in the same domain can synchronize with each other
- "leaderIdentity": The unique identifier (usually MAC address) of the current PTP leader (grandmaster)
- "leaderPriorities": The priority values of the leader used in the Best Master Clock Algorithm (BMCA). Lower values indicate higher priority
- "priority1": Static priority set by the administrator
- "priority2": Dynamic priority based on the leader's role or clock quality
- "leaderAccuracy": The timing offset in seconds from the sample timestamp to the PTP timestamp
- "meanPathDelay": The average round-trip delay between the device and the PTP leader, measured in seconds source: The source of synchronization must be defined as one of the following:
- "vlan": Integer representing the VLAN ID for PTP traffic (e.g., 100 for VLAN 100)
- "leaderTimeSource": Indicates the leader's source of time, such as GNSS, atomic clock, or NTP
- "genlock": The tracking device has an external black/burst or tri-level analog sync signal that is triggering the capture of tracking samples

 "videoIn": The tracking device has an external video signal that is triggering the capture of tracking samples
"ptp": The tracking device is locked to a PTP leader
"ntp": The tracking device is locked to an NTP server
Units
None
Sampling
Regular
Constraints
The parameter shall contain the required valid fields.
timecode
Description
SMPTE timecode of the sample. Timecode is a standard for labeling individual frames of data in media systems and is useful for inter-frame synchronization. Frame rate is a rational number, allowing drop frame rates such as that colloquially called 29.97 to be represented exactly, as 30000/1001. The timecode frame rate may differ from the sample frequency. The zero-based sub-frame field allows for finer division of the frame, e.g. interlaced frames have two sub-frames, one per field.
Units
None
Sampling
Regular
Constraints
The parameter shall contain a valid format and hours, minutes, seconds and frames with appropriate min/max values.
custom
Description
This list provides optional additional custom coefficients that can extend the existing lens model. The meaning of and how these characteristics are to be applied to a virtual camera would require negotiation between a particular producer and consumer.

Units

None

Sampling
Regular
Constraints
The parameter shall be a tuple of items of the class itemClass. The tuple can be empty
distortion
Description
A list of Distortion objects that each define the coefficients for calculating the distortion characteristics of a lens comprising radial distortion coefficients of the spherical distortion (k1-N) and the tangential distortion (p1-N). An optional key 'model' can be used that describes the distortion model. The default is Brown-Conrady D-U (that maps Distorted to Undistorted coordinates).
Units
None
Sampling
Regular
Constraints
The list shall contain at least one Distortion object, and in each object the radial and tangential coefficients shall each be real numbers.
distortionOverscan
Description
Overscan factor on lens distortion. Overscan may be provided by the producer but can also be overriden or calculated by the consumer. Note this should be the maximum of both projection-matrix-based and field-of-view-based rendering as per the OpenLensIO documentation.
Units
None
Sampling
Regular
Constraints
The parameter shall be a real number >= 1.
undistortionOverscan

Description

calculated by the consumer. Note this should be the maximum of both projection-matrix-based and field-of-view-based rendering as per the OpenLensIO documentation.
Units
None
Sampling
Regular
Constraints
The parameter shall be a real number >= 1.
distortionOffset
Description
Offset in x and y of the centre of distortion of the virtual camera
Units
millimeter
Sampling
Regular
Constraints
X and Y centre shift shall each be real numbers.
encoders
Description
Normalised real numbers (0-1) for focus, iris and zoom. Encoders are represented in this way (as opposed to raw integer values) to ensure values remain independent of encoder resolution, minimum and maximum (at an acceptable loss of precision). These values are only relevant in lenses with end-stops that demarcate the 0 and 1 range. Value should be provided in the following directions (if known): Focus: 0=infinite 1=closest Iris: 0=open 1=closed Zoom: 0=wide angle 1=telephoto
Units
None
Sampling

Regular
Constraints
The parameter shall contain at least one normalised values (01) for the FIZ encoders.
entrancePupilOffset
Description
Offset of the entrance pupil relative to the nominal imaging plane (positive if the entrance pupil is located on the side of the nominal imaging plane that is towards the object, and negative otherwise). Measured in meters as in a render engine it is often applied in the virtual camera's transform chain.
Units
meter
Sampling
Regular
Constraints
The parameter shall be a real number.
exposureFalloff
Description
Coefficients for calculating the exposure fall-off (vignetting) of a lens
Units
None
Sampling
Regular
Constraints
The coefficients shall each be real numbers.
fStop
Description
The linear f-number of the lens, equal to the focal length divided by the diameter of the entrance pupil.

Units

Sampling
Regular
Constraints
The parameter shall be a real number greater than 0.
pinholeFocalLength
Description
Distance between the pinhole and the image plane in the simple CGI pinhole camera model.
Units
millimeter
Sampling
Regular
Constraints
The parameter shall be a real number greater than 0.
focusDistance
Description
Focus distance/position of the lens
Units
meter
Sampling
Regular
Constraints
The parameter shall be a real number greater than 0.
projectionOffset
Description

Offset in x and y of the centre of perspective projection of the virtual camera

None

Units
millimeter
Sampling
Regular
Constraints
X and Y projection offset shall each be real numbers.
rawEncoders
Description
Raw encoder values for focus, iris and zoom. These values are dependent on encoder resolution and before any homing / ranging has taken place.
Units
None
Sampling
Regular
Constraints
The parameter shall contain at least one integer value for the FIZ encoders.
tStop
Description
Linear t-number of the lens, equal to the F-number of the lens divided by the square root of the transmittance of the lens.
Units
None
Sampling
Regular
Constraints
The parameter shall be a real number greater than 0.

protocol

Description
Name of the protocol in which the sample is being employed, and version of that protocol
Units
None
Sampling
Regular
Constraints
Protocol name is nonblank string; protocol version is basic x.y.z semantic versioning string
sampleId
Description
URN serving as unique identifier of the sample in which data is being transported.
Units
None
Sampling
Regular
Constraints
The parameter shall be a UUID URN as specified in IETF RFC 4122. Only lowercase characters shall be used. Example: f81d4fae-7dec-11d0-a765-00a0c91e6bf6
sourceId
Description
URN serving as unique identifier of the source from which data is being transported.
Units
None
Sampling
Regular
Constraints
The parameter shall be a UUID URN as specified in IETF RFC 4122. Only lowercase characters shall be

used. Example: f81d4fae-7dec-11d0-a765-00a0c91e6bf6

sourceNumber

Description

Number that identifies the index of the stream from a source from which data is being transported. This is	s most
important in the case where a source is producing multiple streams of samples.	

•
Number that identifies the index of the stream from a source from which data is being transported. This is number that identifies the index of the stream from a source from which data is being transported. This is number that identifies the index of the stream from a source from which data is being transported. This is number that identifies the index of the stream from a source from which data is being transported. This is not important in the case where a source is producing multiple streams of samples.
Units
None
Sampling
Regular
Constraints
The parameter shall be a integer in the range (04,294,967,295].
relatedSampleIds
Description
List of sampleId properties of samples related to this sample. The existence of a sample with a given sampleId is not guaranteed.
Units
None
Sampling
Regular
Constraints
The parameter shall be a tuple of items of the class itemClass. The tuple can be empty
globalStage
Description
Position of stage origin in global ENU and geodetic coordinates (E, N, U, lat0, lon0, h0). Note this may be dynamic if the stage is inside a moving vehicle.
Units
meter
Sampling

Regular

Constraints

Each field in the Global Position shall be a real number

transforms

Description

A list of transforms. Transforms are composed in order with the last in the list representing the X,Y,Z in meters of camera sensor relative to stage origin. The Z axis points upwards and the coordinate system is right-handed. Y points in the forward camera direction (when pan, tilt and roll are zero). For example in an LED volume Y would point towards the centre of the LED wall and so X would point to camera-right. Rotation expressed as euler angles in degrees of the camera sensor relative to stage origin Rotations are intrinsic and are measured around the axes ZXY, commonly referred to as [pan, tilt, roll] Notes on Euler angles: Euler angles are human readable and unlike quarternions, provide the ability for cycles (with angles >360 or <0 degrees). Where a tracking system is providing the pose of a virtual camera, gimbal lock does not present the physical challenges of a robotic system. Conversion to and from quarternions is trivial with an acceptable loss of precision.

Units

meter / degree

Sampling

Regular

Constraints

Each component of each transform shall contain Real numbers.

Reader coverage

The following table indicates the camera parameters supported by each of the readers.

Reader	duration	captureFrameRate	activeSensorPhysicalDimensions	activeSensorResc
RED	+	+	+	
ARRI	+	+	+	
Venice	+	+	+	
Canon	+			

Clip JSON Schema

```
"$id": "https://opentrackio.org/schema.json",
"$schema": "https://json-schema.org/draft/2020-12/schema",
"type": "object",
```

```
"properties": {
 "static": {
   "type": "object",
   "properties": {
      "duration": {
        "type": "object",
        "properties": {
          "num": {
            "type": "integer",
            "maximum": 2147483647,
            "minimum": 1
          },
          "denom": {
            "type": "integer",
            "maximum": 4294967295,
            "minimum": 1
         }
        },
        "required": [
          "num",
          "denom"
        ],
        "additionalProperties": false,
        "description": "Duration of the clip",
        "units": "second"
      },
      "camera": {
        "type": "object",
        "properties": {
          "captureFrameRate": {
            "type": "object",
            "properties": {
              "num": {
                "type": "integer",
                "maximum": 2147483647,
                "minimum": 1
              },
              "denom": {
                "type": "integer",
                "maximum": 4294967295,
                "minimum": 1
              }
            },
            "required": [
              "num",
              "denom"
            ],
            "additionalProperties": false,
            "description": "Capture frame rate of the camera",
            "units": "hertz"
          },
          "activeSensorPhysicalDimensions": {
            "type": "object",
            "properties": {
              "height": {
                "type": "number",
                "minimum": 0.0
```

```
"width": {
      "type": "number",
      "minimum": 0.0
    }
  },
  "required": [
    "height",
    "width"
  ],
  "description": "Height and width of the active area of the camera sensor in micrc
  "additionalProperties": false,
  "units": "millimeter"
},
"activeSensorResolution": {
  "type": "object",
  "properties": {
    "height": {
      "type": "integer",
      "maximum": 2147483647,
      "minimum": 0
    },
    "width": {
      "type": "integer",
      "maximum": 2147483647,
      "minimum": 0
    }
  },
  "required": [
    "height",
    "width"
  ],
  "description": "Photosite resolution of the active area of the camera sensor in p
  "additionalProperties": false,
  "units": "pixel"
},
"make": {
  "type": "string",
  "minLength": 1,
  "maxLength": 1023,
  "description": "Non-blank string naming camera manufacturer"
},
"model": {
  "type": "string",
  "minLength": 1,
  "maxLength": 1023,
  "description": "Non-blank string identifying camera model"
},
"serialNumber": {
  "type": "string",
  "minLength": 1,
  "maxLength": 1023,
  "description": "Non-blank string uniquely identifying the camera"
},
"firmwareVersion": {
  "type": "string",
  "minLength": 1,
```

```
"maxLength": 1023,
      "description": "Non-blank string identifying camera firmware version"
   },
    "label": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string containing user-determined camera identifier"
    "anamorphicSqueeze": {
      "type": "object",
      "properties": {
        "num": {
          "type": "integer",
          "maximum": 2147483647,
          "minimum": 1
       },
        "denom": {
          "type": "integer",
          "maximum": 4294967295,
          "minimum": 1
       }
      },
      "required": [
       "num",
        "denom"
     ],
      "additionalProperties": false,
      "description": "Nominal ratio of height to width of the image of an axis-aligned\
   },
    "isoSpeed": {
      "type": "integer",
      "maximum": 4294967295,
      "minimum": 1,
      "description": "Arithmetic ISO scale as defined in ISO 12232"
    },
    "fdlLink": {
      "type": "string",
      "pattern": "^urn:uuid:[0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12
      "description": "URN identifying the ASC Framing Decision List used by the camera.
   },
    "shutterAngle": {
      "type": "number",
      "maximum": 360.0,
      "minimum": 0.0,
      "description": "Shutter speed as a fraction of the capture frame rate. The shutte
      "units": "degree"
   }
 },
 "additionalProperties": false
"lens": {
 "type": "object",
 "properties": {
    "distortionOverscanMax": {
      "type": "number",
      "minimum": 1.0,
```

},

```
"description": "Static maximum overscan factor on lens distortion. This is alterr
   },
    "undistortionOverscanMax": {
      "type": "number",
      "minimum": 1.0,
     "description": "Static maximum overscan factor on lens undistortion. This is alte
   },
    "make": {
     "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string naming lens manufacturer"
   },
    "model": {
      "type": "string",
      "minLength": 1,
     "maxLength": 1023,
      "description": "Non-blank string identifying lens model"
    "serialNumber": {
      "type": "string",
     "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string uniquely identifying the lens"
   },
    "firmwareVersion": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string identifying lens firmware version"
    },
    "nominalFocalLength": {
     "type": "number",
      "exclusiveMinimum": 0.0,
      "description": "Nominal focal length of the lens. The number printed on the side\
      "units": "millimeter"
   },
    "calibrationHistory": {
      "type": "array",
      "description": "List of free strings that describe the history of calibrations of
      "items": {
        "type": "string",
        "minLength": 1,
        "maxLength": 1023
     }
   }
 },
 "additionalProperties": false
"tracker": {
 "type": "object",
 "properties": {
    "make": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string naming tracking device manufacturer"
```

},

```
"model": {
          "type": "string",
          "minLength": 1,
          "maxLength": 1023,
          "description": "Non-blank string identifying tracking device model"
        },
        "serialNumber": {
          "type": "string",
          "minLength": 1,
          "maxLength": 1023,
          "description": "Non-blank string uniquely identifying the tracking device"
        },
        "firmwareVersion": {
          "type": "string",
          "minLength": 1,
          "maxLength": 1023,
          "description": "Non-blank string identifying tracking device firmware version"
      },
      "additionalProperties": false
    }
  },
  "additionalProperties": false
},
"tracker": {
  "type": "object",
  "properties": {
    "notes": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string containing notes about tracking system"
    },
    "recording": {
      "type": "boolean",
      "description": "Boolean indicating whether tracking system is recording data"
    },
    "slate": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string describing the recording slate"
    },
    "status": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "description": "Non-blank string describing status of tracking system"
    }
  },
  "additionalProperties": false
},
"timing": {
  "type": "object",
  "properties": {
    "mode": {
```

```
"enum": [
    "internal",
    "external"
  ],
  "type": "string",
 "description": "Enumerated value indicating whether the sample transport mechanism\nr
},
"recordedTimestamp": {
  "type": "object",
  "properties": {
    "seconds": {
      "type": "integer",
      "maximum": 281474976710655,
      "minimum": 0
    },
    "nanoseconds": {
      "type": "integer",
      "maximum": 4294967295,
      "minimum": 0
   }
  },
  "required": [
    "seconds",
    "nanoseconds"
  ],
  "additionalProperties": false,
  "units": "second",
  "description": "PTP timestamp of the data recording instant, provided for convenience
},
"sampleRate": {
  "type": "object",
  "properties": {
    "num": {
      "type": "integer",
      "maximum": 2147483647,
      "minimum": 1
    },
    "denom": {
      "type": "integer",
      "maximum": 4294967295,
      "minimum": 1
    }
  },
  "required": [
    "num",
    "denom"
  ],
  "additionalProperties": false,
  "description": "Sample frame rate as a rational number. Drop frame rates such as\n29.
},
"sampleTimestamp": {
  "type": "object",
  "properties": {
    "seconds": {
      "type": "integer",
      "maximum": 281474976710655,
      "minimum": 0
```

```
"nanoseconds": {
      "type": "integer",
      "maximum": 4294967295,
      "minimum": 0
   }
  },
  "required": [
    "seconds",
    "nanoseconds"
  "additionalProperties": false,
  "units": "second",
  "description": "PTP timestamp of the data capture instant. Note this may differ\nfrom
},
"sequenceNumber": {
  "type": "integer",
  "maximum": 4294967295,
  "minimum": 0,
  "description": "Integer incrementing with each sample."
},
"synchronization": {
  "type": "object",
  "properties": {
    "locked": {
      "type": "boolean"
   },
    "source": {
      "enum": [
        "genlock",
        "videoIn",
        "ptp",
        "ntp"
      "type": "string"
    "frequency": {
      "type": "object",
      "properties": {
        "num": {
          "type": "integer",
          "maximum": 2147483647,
          "minimum": 1
        },
        "denom": {
          "type": "integer",
          "maximum": 4294967295,
          "minimum": 1
        }
      },
      "required": [
        "num",
        "denom"
      ],
      "additionalProperties": false
    },
    "offsets": {
```

```
"type": "object",
  "properties": {
    "translation": {
      "type": "number"
    },
    "rotation": {
      "type": "number"
    "lensEncoders": {
      "type": "number"
    }
  },
  "additionalProperties": false
},
"present": {
  "type": "boolean"
},
"ptp": {
  "type": "object",
  "properties": {
    "profile": {
      "enum": [
        "IEEE Std 1588-2019",
        "IEEE Std 802.1AS-2020",
        "SMPTE ST2059-2:2021"
      ],
      "type": "string"
    },
    "domain": {
      "type": "integer",
      "maximum": 127,
      "minimum": 0
    },
    "leaderIdentity": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023,
      "pattern": "(?:^[0-9a-f]{2}(?::[0-9a-f]{2}){5}$)|(?:^[0-9a-f]{2}(?:-[0-9a-f]{
    },
    "leaderPriorities": {
      "type": "object",
      "properties": {
        "priority1": {
          "type": "integer",
          "maximum": 255,
          "minimum": 0
        },
        "priority2": {
          "type": "integer",
          "maximum": 255,
          "minimum": 0
        }
      },
      "required": [
        "priority1",
        "priority2"
      ],
```

```
"description": "Data structure for PTP synchronization priorities",
          "additionalProperties": false
        },
        "leaderAccuracy": {
          "type": "number",
          "minimum": 0.0
        },
        "leaderTimeSource": {
          "enum": [
            "GNSS",
            "Atomic clock",
            "NTP"
          "type": "string"
        },
        "meanPathDelay": {
          "type": "number",
          "minimum": 0.0
        },
        "vlan": {
          "type": "integer",
          "maximum": 4294967295,
          "minimum": 0
        }
      },
      "required": [
        "profile",
        "domain",
        "leaderIdentity",
        "leaderPriorities",
        "leaderAccuracy",
        "meanPathDelay"
      "additionalProperties": false
   }
  },
  "required": [
    "locked",
    "source"
  ],
  "additionalProperties": false,
  "description": "Object describing how the tracking device is synchronized for this\ns
},
"timecode": {
  "type": "object",
  "properties": {
    "hours": {
      "type": "integer",
      "maximum": 23,
      "minimum": 0
    },
    "minutes": {
      "type": "integer",
      "maximum": 59,
      "minimum": 0
    },
    "seconds": {
```

```
"type": "integer",
          "maximum": 59,
          "minimum": 0
        },
        "frames": {
          "type": "integer",
          "maximum": 119,
          "minimum": 0
        },
        "frameRate": {
          "type": "object",
          "properties": {
            "num": {
              "type": "integer",
              "maximum": 2147483647,
              "minimum": 1
            },
            "denom": {
              "type": "integer",
              "maximum": 4294967295,
              "minimum": 1
            }
          },
          "required": [
            "num",
            "denom"
          ],
          "additionalProperties": false
        },
        "subFrame": {
          "type": "integer",
          "maximum": 4294967295,
          "minimum": 0
        }
      },
      "required": [
        "hours",
        "minutes",
        "seconds",
        "frames",
        "frameRate"
      ],
      "description": "SMPTE timecode of the sample. Timecode is a standard for labeling\nir
      "additionalProperties": false
    }
  },
  "additionalProperties": false
"lens": {
  "type": "object",
  "properties": {
    "custom": {
      "type": "array",
      "items": {
        "type": "number"
      "description": "This list provides optional additional custom coefficients that can \
```

},

```
"distortion": {
  "type": "array",
  "items": {
    "type": "object",
    "properties": {
      "radial": {
        "type": "array",
        "items": {
          "type": "number"
        },
        "minItems": 1
      },
      "tangential": {
        "type": "array",
        "items": {
         "type": "number"
        },
        "minItems": 1
      },
      "model": {
        "type": "string",
        "minLength": 1,
        "maxLength": 1023
      }
    },
    "required": [
      "radial"
    "additionalProperties": false
  "minItems": 1,
  "description": "A list of Distortion objects that each define the coefficients for\nc
"distortionOverscan": {
  "type": "number",
  "minimum": 1.0,
  "description": "Overscan factor on lens distortion. Overscan may be provided by the\r
},
"undistortionOverscan": {
  "type": "number",
  "minimum": 1.0,
  "description": "Overscan factor on lens undistortion. Overscan may be provided by the
},
"distortionOffset": {
  "type": "object",
  "properties": {
    "x": {
     "type": "number"
    },
    "v": {
     "type": "number"
  },
  "required": [
    "x",
    "у"
```

```
"additionalProperties": false,
  "description": "Offset in x and y of the centre of distortion of the virtual camera",
  "units": "millimeter"
},
"encoders": {
  "type": "object",
  "properties": {
    "focus": {
      "type": "number",
      "maximum": 1.0,
      "minimum": 0.0
    },
    "iris": {
      "type": "number",
      "maximum": 1.0,
      "minimum": 0.0
    },
    "zoom": {
      "type": "number",
      "maximum": 1.0,
      "minimum": 0.0
    }
  },
  "additionalProperties": false,
  "description": "Normalised real numbers (0-1) for focus, iris and zoom.\nEncoders are
  "any0f": [
    {
      "required": [
        "focus"
      ]
    },
    {
      "required": [
        "iris"
      ]
    },
      "required": [
       "zoom"
      1
    }
  ]
},
"entrancePupilOffset": {
  "type": "number",
  "description": "Offset of the entrance pupil relative to the nominal imaging plane\n(
  "units": "meter"
},
"exposureFalloff": {
  "type": "object",
  "properties": {
    "a1": {
      "type": "number"
    },
    "a2": {
      "type": "number"
```

```
"a3": {
     "type": "number"
  },
  "required": [
   "a1"
  ],
  "additionalProperties": false,
  "description": "Coefficients for calculating the exposure fall-off (vignetting) of\na
},
"fStop": {
  "type": "number",
  "exclusiveMinimum": 0.0,
  "description": "The linear f-number of the lens, equal to the focal length divided\nk
},
"pinholeFocalLength": {
  "type": "number",
  "exclusiveMinimum": 0.0,
  "description": "Distance between the pinhole and the image plane in the simple CGI pi
  "units": "millimeter"
},
"focusDistance": {
  "type": "number",
  "exclusiveMinimum": 0.0,
  "description": "Focus distance/position of the lens",
  "units": "meter"
},
"projectionOffset": {
  "type": "object",
  "properties": {
    "x": {
     "type": "number"
    },
    "y": {
     "type": "number"
    }
  "required": [
    "x",
    "y"
  ],
  "additionalProperties": false,
  "description": "Offset in x and y of the centre of perspective projection of the\nvir
  "units": "millimeter"
"rawEncoders": {
  "type": "object",
  "properties": {
    "focus": {
      "type": "integer",
      "maximum": 4294967295,
      "minimum": 0
    },
    "iris": {
      "type": "integer",
      "maximum": 4294967295,
```

```
"minimum": 0
        },
        "zoom": {
          "type": "integer",
          "maximum": 4294967295,
          "minimum": 0
        }
      },
      "additionalProperties": false,
      "description": "Raw encoder values for focus, iris and zoom.\nThese values are depend
      "any0f": [
        {
          "required": [
           "focus"
          ]
        },
        {
          "required": [
           "iris"
          ]
        },
        {
          "required": [
           "zoom"
          ]
      ]
    },
    "tStop": {
      "type": "number",
      "exclusiveMinimum": 0.0,
      "description": "Linear t-number of the lens, equal to the F-number of the lens\ndivic
    }
 },
  "additionalProperties": false
"protocol": {
  "type": "object",
  "properties": {
    "name": {
      "type": "string",
      "minLength": 1,
      "maxLength": 1023
    },
    "version": {
      "type": "array",
      "items": {
        "type": "integer",
        "maximum": 9,
        "minimum": 0
      "minItems": 3,
      "maxItems": 3
    }
  },
  "required": [
    "name",
```

```
"version"
  ],
  "additionalProperties": false,
  "description": "Name of the protocol in which the sample is being employed, and\nversion
},
"sampleId": {
 "type": "string",
  "pattern": "^urn:uuid:[0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12}$",
  "description": "URN serving as unique identifier of the sample in which data is\nbeing tr
},
"sourceId": {
  "type": "string",
  "pattern": "^urn:uuid:[0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12}$",
  "description": "URN serving as unique identifier of the source from which data is\nbeing
},
"sourceNumber": {
  "type": "integer",
  "maximum": 4294967295,
  "minimum": 0,
  "description": "Number that identifies the index of the stream from a source from which\r
},
"relatedSampleIds": {
  "type": "array",
  "items": {
    "type": "string",
    "pattern": "^urn:uuid:[0-9a-f]{8}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{4}-[0-9a-f]{12}$"
 },
  "description": "List of sampleId properties of samples related to this sample. The\nexist
},
"globalStage": {
  "type": "object",
  "properties": {
    "E": {
     "type": "number"
    },
    "N": {
      "type": "number"
    },
    "U": {
     "type": "number"
    "lat0": {
      "type": "number"
    },
    "lon0": {
     "type": "number"
    },
    "h0": {
     "type": "number"
    }
  },
  "required": [
    "E",
    "N",
    "U",
    "lat0",
    "lon0",
```

```
"h0"
  ],
  "description": "Position of stage origin in global ENU and geodetic coordinates\n(E, N, L
  "additionalProperties": false,
  "units": "meter"
},
"transforms": {
  "type": "array",
  "items": {
    "type": "object",
    "properties": {
      "translation": {
        "type": "object",
        "properties": {
          "x": {
            "type": "number"
          },
          "y": {
           "type": "number"
          },
          "z": {
           "type": "number"
          }
        },
        "additionalProperties": false,
        "units": "meter"
      },
      "rotation": {
        "type": "object",
        "properties": {
          "pan": {
           "type": "number"
          },
          "tilt": {
           "type": "number"
          "roll": {
            "type": "number"
          }
        },
        "additionalProperties": false,
        "units": "degree"
      },
      "scale": {
        "type": "object",
        "properties": {
          "x": {
            "type": "number"
          },
          "y": {
           "type": "number"
          },
          "z": {
           "type": "number"
          }
        },
        "additionalProperties": false
```

```
"id": {
           "type": "string",
           "minLength": 1,
           "maxLength": 1023
         }
       },
        "required": [
         "translation",
         "rotation"
        "additionalProperties": false
     },
     "minItems": 1,
     "description": "A list of transforms.\nTransforms are composed in order with the last in
     "units": "meter / degree",
     "uniqueItems": false
   }
 }
}
```